Lab Report

Your Score: 4 of 5 (80%)

Elapsed Time: 9 minutes 42 seconds

- 💢 Connect the CorpDMZWeb server to the Optional Port on the NSA
- ✓ Configure the Optional Port for DMZ mode
- ✓ Configure the DMZ zone for DHCP Show Details
- ✓ Configure a reserved IP address for the CorpDMZWeb server Show Details
- ✓ Configure the DMZ server to obtain an IP address automatically

Explanation

To create the DMZ, complete the following steps:

Connect the Server to the NSA

- 1. In the Basement, switch to the Back view of the server rack.
- 2. Expand the Cables group on the Shelf, and select the Cat5e cable.
- 3. In the Selected Component window, click on one end of the network cable and drag it to the left Ethernet port on the **CorpDMZWeb** server.
- 4. In the Selected Component window, click on the other end of the network cable and drag it to the **Optional Port** on the NSA.

Configure the DMZ

- 1. From the top, navigate to the IT Administrator's office by selecting **Building A** > **Floor 1**; then select **ITAdmin**.
- 2. Click **Start** > **Internet Explorer**.
- 3. Enter the NSA Management address (198.28.56.18) in the URL field, and press Enter. Maximize Internet Explorer to allow for easier viewing.
- 4. Login to the Security Appliance Configuration Utility using the new username (**mbrown**) and password (**St@y0ut!**).
- 5. In the left pane under Getting Started, click Advanced.
- 6. Under DMZ Port, select **Set Optional Port to DMZ Mode**.
- 7. Select DMZ, and click Apply.
- 8. In the left pane, select DMZ Config.
- 9. On the DMZ Configuration page, set the DHCP mode to **DHCP Server**, add the DNS Server addresses (**163.128.78.93** and **163.128.80.93**), and click **Apply**.
- 10. In the left pane, select DMZ Reserved IPs.
- 11. On the DMZ Reserved IPs page, click Add.
- 12. Enter the first IP Address in the range (172.16.2.100) and the MAC Address (1A:2B:C4:28:3B:9F), and then click Apply.

Configure DMZ Server Networking

- 1. Navigate back to the Basement and select **CorpDMZWeb**.
- 2. Right-click the Network icon in the system tray, and then select Open Network and Sharing Center.
- 3. Click Change adapter settings.
- 4. Right-click **Ethernet**, and then select **Properties**.
- 5. Select Internet Protocol Version 4 (TCP/IPv4), and then click Properties.

- 6. Select **Obtain an IP address automatically** and **Obtain DNS server address automatically**, and then click **OK**.
- 7. Click **Close**, and then on the back arrow to return to Network and Sharing Center.
- 8. Click **Ethernet**. (The Ethernet Status window may open behind Explorer.)
- 9. Click **Details** to verify that the server has received the correct IP Address.